

Installation Guide: Security Hardware

Hanging with security hardware is done in two parts. First, install the hanging hardware, then install the security T-head screw to lock the artwork to the wall.

1. Choose desired location for artwork and lightly mark the wall at the top edge of artwork with a pencil.
2. Locate the mounting plates on the top back side of the canvas and measure the distance between the centers.
3. Using the measurement determined by step 2, mark the wall 1 1/4" below the line made in step 1 so that it is centered. Be sure to use a level.
4. Drill two 5/16" holes in the locations marked in step 3. Holes should be 1 1/4" down from where the top edge of the artwork will be. The distance between should be equivalent to the measurement from Step 2. Double check that they are level.
5. Use 1" screws and plastic anchors (provided) to attach wall bracket to each hole so that the flanged end of the bracket faces up and away from the wall. Do not over tighten screws.
6. Hook the upper flanged ends of the wall brackets snugly between the mounting plates and the artwork. The art should now be sitting securely on the wall.
7. If the artwork is not level, small adjustments are possible by removing the art from the wall, loosening the wall bracket screws slightly shifting the brackets up or down in their slots as needed. Once moved, retighten screws and replace the artwork on the brackets.

Now that the hanging hardware is installed, the security T-head screw must be accurately installed on the wall. Improper placement will result in an inability to lock the artwork to the wall.

8. Use a pencil to mark where the bottom center of the mounting plate hits the wall.
9. For professional installers: mounting plates have two points of contact on the mounting bracket. Apply pressure to solid edge of artwork to use as placement reference.
10. Remove the artwork from the wall.
11. Drill a 5/16" diameter hole at the pencil mark and use the T-head plastic anchor (provided with purchase) into the drilled hole. Gently hammer into place until flush with wall surface.
12. Thread the T-head screw (provided) into the anchor until it extends approx 3/8" from wall surface. Start threading first by hand and then use the security wrench (provided). Align the head of the screw to a final **horizontal** position so it slides into the slot in the mounting plate.
13. Hang the artwork back on the wall brackets. The T-head screw just installed should fall inside the slot of the mounting plate on the bottom back of the artwork.
14. From the right hand side, slide the security wrench underneath the bottom edge of the canvas artwork and without lifting the canvas away from the wall, engage and rotate the T-head screw clockwise one quarter turn to a **vertical** position.

Your artwork is now locked to the wall.



Mounting Plate



Wall Brackets, Anchors and Screws



T-head Screw and Anchor



Security Wrench



Locked Security Hardware Unit